


3 & 4 Way Instructions on Adjusting



- A. Gravity Head**
- B. Adjustable Connecting Slot**
- C. Feed Dispensing Ports**

1. Attach gravity head to the feeder hopper.
2. Adjust the inner sleeve of the gravity head by pushing the head itself up or down. Start all the way up.
3. Pour a small portion of preferred material (corn, protein, etc.) into the hopper. Push gravity head down (slowly) until desired flow is achieved.
4. Snug bolts down.

Return policy: We will not exchange, refund or replace, if item has been modified.